



Gearbox Capabilities

| Part Number | Manufacturer | Description |
|--------------------|---------------------|--------------------|
| 251N4204-SERIES | BOEING | GEARBOX |
| 251N4218-SERIES | BOEING | GEARBOX |
| 251N4222-SERIES | BOEING | GEARBOX |
| 251N4241-SERIES | BOEING | GEARBOX |
| 251N5082-SERIES | BOEING | GEARBOX |
| 251N5091-SERIES | BOEING | GEARBOX 757 |
| 5-84048-3001 | BOEING | FLAP DR GEARBOX |
| 5-84048-3002 | BOEING | FLAP DR GEARBOX |
| 5-84048-SERIES | BOEING | FLAP DR GEARBOX |
| 5-87448-SERIES | BOEING | FLAP DR GEARBOX |
| 5-96770-SERIES | BOEING | FLAP DR GEARBOX |
| 5-97039-SERIES | BOEING | FLAP DR GEARBOX |
| 65-20845-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-20846-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-20848-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-20852-1 | BOEING | FLAP DRIVE GEARBOX |
| 65-20852-2 | BOEING | FLAP DRIVE GEARBOX |
| 65-20852-3 | BOEING | FLAP DRIVE GEARBOX |
| 65-20852-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-21945-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-22819-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-22944-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-23467-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-23557-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-24400-SERIES | BOEING | GEARBOX 727 |
| 65-24525-SERIES | BOEING | GEARBOX |
| 65-46360-SERIES | BOEING | GEARBOX 737 |
| 65-51500-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-51510-1 | BOEING | FLAP DRIVE GEARBOX |
| 65-51510-2 | BOEING | FLAP DRIVE GEARBOX |
| 65-51510-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-51513-1 | BOEING | FLAP DRIVE GEARBOX |
| 65-51513-2 | BOEING | FLAP DRIVE GEARBOX |

| | | |
|-----------------|--------|--------------------|
| 65-51513-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-52283-SERIES | BOEING | GEARBOX 737 |
| 65-52284-SERIES | BOEING | GEARBOX 737 |
| 65-6372-1 | BOEING | FLAP DRIVE GEARBOX |
| 65-6372-2 | BOEING | FLAP DRIVE GEARBOX |
| 65-6372-3 | BOEING | FLAP DRIVE GEARBOX |
| 65-6372-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-6373-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-63851-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-7290-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-7485-1 | BOEING | FLAP DRIVE GEARBOX |
| 65-7485-3 | BOEING | FLAP DRIVE GEARBOX |
| 65-7485-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 65-75960-SERIES | BOEING | GEARBOX 737 |
| 65B60044-1 | BOEING | GEARBOX |
| 65B60044-SERIES | BOEING | GEARBOX |
| 69-27991-1 | BOEING | FLAP DRIVE GEARBOX |
| 69-27991-2 | BOEING | FLAP DRIVE GEARBOX |
| 69-27991-SERIES | BOEING | FLAP DRIVE GEARBOX |
| 9-55633-3000 | BOEING | FLAP DRIVE GEARBOX |
| 9-55633-3001 | BOEING | FLAP DRIVE GEARBOX |
| 9-55633-SERIES | BOEING | FLAP DRIVE GEARBOX |